


Subject to change, production tolerances have to be taken into account.


TUNING CENTER MODIFICATION acc. 'TC 020.06200TC'



Symbolic crane figure, indications at 20° main boom position & load arm in horizontal position

Lifting capacity diagram PK 92002-SH F PJ170 E

Subject to change, production tolerances have to be taken into account.



When using mechanical boom extensions, the loads shown on the charts need to be reduced by the weight of these extensions.
Symbolic crane figure, indications at ° main boom position & load arm in horizontal position